




Quick Installation Guide


LTE-Advanced Mobile Wi-Fi

Install the SIM Card and Battery


1 Remove the back cover.



2 Slide and lift up the SIM card slot cover.




3 Insert the SIM card and slide the cover back to lock.




- A nano SIM card must be converted using the provided SIM card tray.
- The micro SD card slot can be used for storage and media sharing.
- The SIM card and SD card are not provided.

4 Install the provided battery.



5 Replace the cover.




Connect to the Internet

1 Press and hold the button until the welcome screen appears.




- ! To power off, press and hold the button until the "Power Off" message appears on the screen.

2 You will find the following messages on the screen, and then follow the instructions to connect to the Mobile Wi-Fi.



Press the button twice and then press the button to select **Device Info**. Use the **SSID** and **Password** shown on the screen to connect to your Mobile Wi-Fi.



Enjoy!




- ! If other messages display on the screen, please refer to FAQ > Q3.
- By default, Power Saving is enabled and the Wi-Fi will be turned off when no wireless devices are connected to the Mobile Wi-Fi for 10 minutes. Press the or button to resume the Wi-Fi connection.

Screen Display


The screen display will automatically turn off after being idle for 15 seconds. Press the or button to turn it on again.

Home Screen



Menu Screen

Select the icons to view and customize various functions.



- Signal Strength
- Wi-Fi Status and Connected Devices
- Internet Connection and Network Type
- Battery Life
- Data Roaming
- Total Data Usage
- Message
- Download Speed

- Home
- WPS
- Device Info
- Wi-Fi Band
- Power Saving
- Network Mode
- Data Roaming
- App Download

tpMiFi App

Download the tpMiFi app to conveniently manage your Mobile Wi-Fi.

- Modify Wi-Fi settings
- Send and receive SMS
- Manage battery
- Share files on the SD card
- Block devices

How to start?


- Search for the tpMiFi app from Apple App Store or Google Play Store, or scan the QR code.
- Connect your wireless device to the Mobile Wi-Fi.
- Launch tpMiFi and enter **admin** to log in.



Charging Your Mobile Wi-Fi


Method 1

Via a Wall Outlet (Recommended)



Method 2

Via a Computer



- When on the battery icon disappears, the Mobile Wi-Fi is fully charged.
- The power adapter is not provided by TP-Link.

FAQ (Frequently Asked Questions)

Q1. Is there any alternative to manage the Mobile Wi-Fi besides the tpMiFi app?

- A. You can manage the Mobile Wi-Fi by using its web management page.
- Connect your wireless device to the Mobile Wi-Fi.
 - Launch a web browser and enter <http://tplinkmifi.net> or <http://192.168.0.1> in to the address bar. Enter **admin** for the Password, and then click Login.

Q2. What should I do if I cannot log in to the web management page?

- A1. Verify that your device is connected to the Mobile Wi-Fi.
 A2. Verify that you have entered <http://tplinkmifi.net> or <http://192.168.0.1> correctly.
 A3. Verify that your device is set to obtain an IP address automatically.

Q3. What should I do when one of the following messages appears on the screen or I cannot access the internet?

- A1. PIN Required
- Log in to the web management page. Enter the PIN code provided your mobile carrier, and click **Done**.
- A2. No SIM Card
- Power off the Mobile Wi-Fi and reinstall your SIM card.

A3. No Service

- Verify that your SIM card is an LTE, UMTS or GSM SIM card;
- Verify that your SIM card is in your mobile carrier's service area and has sufficient credit;
- Verify that your mobile carrier parameters are correct:
 On your phone, log in to the web management page, go to **Dial-up > Dial-up Settings** to verify that APN (Access Point Name), Username and Password are correct. If not, click **Create** to create a new profile with the correct information and click **Save**.

A4. icon

- Press the and buttons to select **Data Roaming**, and then turn on **Data Roaming**.

Q4. What should I do if my internet speed is slow?

- A1. If you are experiencing intermittent slow internet connection, you can go to **Wi-Fi Band** on the screen to switch between 2.4GHz and 5GHz band for better connectivity.
- A2. The 4G network may be temporarily unavailable in your current location. From the Menu screen, go to **Network Mode** and try a different network.

Q5. How do I restore the Mobile Wi-Fi to its factory default settings?

- A. With the Mobile Wi-Fi powered on, remove the back cover, and then use a pin to press and hold the **reset** button until **"Power Off"** appears on the screen.

Note: Restoring the Mobile Wi-Fi to its factory defaults will clear all previous settings and you have to reconfigure them.

For technical support and other information, please visit <http://www.tp-link.com/support>, or simply scan the QR code.



Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- Do not use the device where wireless devices are not allowed.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

